




The illustration above displays the ceiling mounting arrangement for the CF 210/CF 210-N loudspeaker and identifies the essential hardware supplied.

Components

- Eye Bolts:
- Safety Chain with S-Hooks or Chain/ M6 steel Rope
- M8 Anchor bolts

CF 210 / CF 210-N Chain Suspension

Application Guidance

- o Remove the bolts fixed on the Loudspeaker
- o Insert rated eye bolts on suspension points on top and behind the Loudspeaker.
- o Attach chain or wire to load-bearing ceiling.
- o Suspend loudspeaker ensuring level alignment.
- o Verify suspension safety before use.

Caution: Suspending a loudspeaker is a skilled job and needs a properly trained technician to undertake the installation ensuring all safety norms are adhered to as per your local authorities and laws.